



When freezing temperatures come...



Will your coils drain fast enough?

DRAIN BEFORE THE DAMAGE

Prevent freezing temperatures from destroying your equipment. Use IHT's free draining coils to drain coils before freeze damage takes place.

IHT's free draining coils are proven to drain before freezing water can damage the coils, in temperatures as low as 4°F.



Contact IHT with your design requirements at:

sales@iht-inc.com



INDUSTRIAL HEAT TRANSFER, INC.

608-452-3103
www.iht-inc.com

300 Old Mill Road
Coon Valley WI 54623